
Self-regulation Classroom Bike Desktop and Backrest Kit



Assembly Guide

Check out our other products online at **www.copernicused.com**For assistance, please contact us by telephone at **1-800-267-8494** or email at **info@copernicused.com**.
Have your packing slip ready for reference.

*Bike sold separately



Large Desktop and Backrest Kit Grades PreK-2 for Self-regulation Classroom Bikes (SCC302-AC)



Large Desktop and Backrest Kit Grades 3-6 for Self-regulation Classroom Bikes (SCC402-AC)



Customer Service & Warranty Information

Dear Educator,

Thank you for purchasing the Self-regulation Classroom Bike Desktop and Backrest Kit. We hope it meets your expectations and you and your students enjoy using it at your school.

Every day we see and hear stories of teachers going above and beyond to help students thrive. Thank you so much for all you do – you are awesome, and you make a difference.

Thank you for inspiring us.

If you have any questions, concerns or ideas on how we can improve please let us know by contacting our Customer Service team at 1-800-267-8494 or *info@copernicused.com*.

Happy teaching,

Kaylyn Belcourt, President kaylyn@copernicused.com

Belieut

We do not inherit the earth from our ancestors, we borrow it from our children.

Change is the end result of all true learning.

What you leave behind is not what is engraved in stone monuments, but what is woven into the lives of others.

Education is the most powerful weapon which you can use to change the world.

- NATIVE AMERICAN PROVERB

- LEO BUSCAGLIA

- PERICLES

- NELSON MANDELA

For missing parts and other issues regarding your product:

Please contact Customer Service, where we will be happy to help. Telephone: 1-800-267-8494, Monday - Friday 8:00am - 4:30 pm EST Email: info@copernicused.com

Need Support? Have a Question?



Email **Customer** Service

Check out some of our other great products!



www.copernicused.com



Register your Product

Registering your warranty ensures we have all the information we need to make any future warranty claims quick and easy. Please visit **www.copernicused.com/warranty** and complete the form within 10 business days from product assembly. By registering your product, you will be entered into a draw to win Copernicus product.



Make a Warranty Claim

We offer a Lifetime Warranty on almost everything we make. Please call **1-800-267-8494** or email **info@copernicused.com** to start your warranty claim. Proof of purchase will be required upon warranty claim (i.e. copy of invoice).

Tips for Assembly

Before You Begin:

- Lay out and identify all of the included parts.
- The hardware has been packed according to step.
- Read the assembly guide over once to familiarize yourself with them.

As You Assemble the Unit:

- Follow the steps in sequence.
- Before beginning each step, find the part(s) that you need for that step.
- The title of each step states what you will be doing. Review the text and the pictures as you build the unit.

Watch for These Helpful Symbols:



For safety, please have someone help you when working on steps displaying this symbol.



The symbol denotes a step needing extra attention to ensure it is done correctly.



Important Information! Warning!

Please read the warnings below for important safety information regarding your product. Failure to read these warnings or to follow the instructions below could result in personal injury or damage to your product that could void your warranty.



Small Parts

In its unassembled state, this product contains parts that can be hazardous to small children. This product should be assembled by an adult.



Adult Supervision

This product is to be used under the supervision of an adult.




Indoor Use Only

This product is intended for indoor commercial use only. The internal components are not sealed from the environment.

INSTALLATION

BEFORE USING

Minimum clearance required around equipment for access to, passage around and emergency dismount. Minimum dimensions are 0.5m (19.7in) on at least one side and 0.5m (19.7in) either behind or in front of the bike.




Actual area for access/passage is the responsibility of the facility and should take into account this training envelope, ADA Accessibility Guideline requirements and any required local codes or regulations.

- 1. As with all exercise equipment or programs, consult a physician prior to use and stop if you feel faint, dizzy
- 2. The equipment should only be used in a supervised environment.
- 3. The equipment must be set up and operated on a solid, level surface.
- 4. A complete visual inspection and test of the features and functions of the assembled Self-regulation Classroom Classroom Bike Desktop and Backrest Kit is to be made prior to use. Immediately report worn, loose or damaged equipment to the teacher and refrain from using the bike.
- 5. Keep body and clothing free and clear of all moving parts.
- 6. Ensure all adjustments and locking features are properly secured before using bike.
- 7. No adjustment should be made, which may limit the movements of the user.
- 8. This equipment is not intended for athletic training purposes.
- 9. Maximum user capacity is 143lbs/65kgs


How to Adjust Seat and Desktop Height

SCC302 / SCC302-G Base Grades PreK-2

4-8 Year Olds



Total Product Weight 14.1kg/(31lb)



Total Product Weight 14.6kg/(32.2lb)

Warning! Do not pedal backwards for a prolonged period of time. This can lead to possible injury and damaged parts. Refer to "Tips" page at the back of this manual for more info.

How to Adjust Desktop Post

To adjust the desktop height, first turn the knob counter-clockwise approximately 3 turns to loosen it.

Next, pull the knob, slide the post up or down to the desired position, and then release the knob.


Move the post up or down slightly until you feel a pop, to make sure that the knob is engaged in one of the adjustment holes in the seat post. Then, turn the knob clockwise to tighten it firmly.


How to Adjust Seat Post and Saddle Position

To adjust the seat, first turn the knob counter-clockwise approximately 3 turns to loosen it.

Next, pull the knob, slide the post up or down to the desired position, and then release the knob.


Move the post up or down slightly until you feel a pop, to make sure that the knob is engaged in one of the adjustment holes in the seat post. Then, turn the knob clockwise to tighten it firmly.







Parts

Before beginning, you should have:






Assemble Desktop




You will need: (Not to Scale)



Replace Handlebars with Desktop









You will need: (Not to Scale)





Comfortable Riding Position Tips



Each rider should adjust to their own comfortable riding position.

- Adjust seat to the height of your hip bone.
- You should be able to reach the desktop easily, keeping your elbows slightly bent.
- To tighten a pedal strap, pull upward on the end of the strap to release tab from slot. Move strap to desired slot, press the tab through strap to secure.

How To Safely Move Your Classroom Bike

