




**Do Not Use Power
Tools for Assembly**

Cozy Space Arch with Shelves

SKU:

W-B-A



Important Information!



Adult Supervision

This product contains small parts when unassembled that can be hazardous to small children, and should be used under the supervision of an adult.



Climb Hazard

Do not climb on, hang on, or suspend objects from any component of this product unless otherwise specified.



Indoor Use Only

This product is intended for indoor commercial use only. To reduce risk of damage, do not expose this product to rain or moisture.



For missing parts and other issues regarding your product:

Please contact customer service, where we will be happy to help.
1-800-267-8494 Monday - Friday 8:00am - 4:30pm EST
info@copernicused.com



Register Your Product

Register your product to make future warranty claims quick and easy.

Visit:

www.copernicused.com/warranty

Make a Warranty Claim

We offer a lifetime warranty and free replacement parts on almost everything we make.

Call **1-800-267-8494** or

email [**info@copernicused.com**](mailto:info@copernicused.com)

Proof of purchase required.

Tips for Assembly:



2-Person Task

For safety, please have someone help you when working on steps displaying this symbol.



The symbol denotes a step needing extra attention to ensure it is done correctly.

Wood & Softouch Maintenance:



When needed, wipe down with mild soapy water.

Wipe cleaning solution off immediately after use.

Recommended cleaning is once monthly, and at minimum, once per school year.

Harsh chemicals like bleach and ammonia based cleaners can be hard on surface finishes. If disinfecting using harsh chemicals is required, we recommend:

50:1 - Water : Bleach solution

DO NOT leave standing water/solution on product.

DO NOT use abrasive cleaners or sponges


Organic materials, including birch and other woods, feature natural variations in color and grain pattern, and visual irregularities where growth nodes or knots exist. The particular color or pattern of any one part or product may vary from one item to another, and it may change slightly with age. These natural variations are considered normal and do not constitute a defect covered under warranty.




Parts

Before beginning, you should have:


Arch Top
2x
391248




Arch Bottom Right
2x
391247




Arch Bottom Left
2x
391246



Bookshelf
2x



Support Rod Long
2x
332501



Support Rod Short
4x
332502

Hardware

M6x19mm Screw
12x
(43219)



1/4" x 3/4" Screw
12x
(430039)



M6 Flat Washer
12x
(432731)



1/4" Flat Washer
12x
(43019)




M6 Lock Washer
12x
(43273)



1/4" Lock Washer
12x
(43010)




Tools



Phillips Screw Driver 1x

1



Hardware

1/4" x 3/4" Screw
12x
(430039)




1/4" Lock Washer
12x
(43010)



1/4" Flat Washer
12x
(43019)




Tools



Phillips Screw Driver 1x

2



Hardware

M6x19mm Screw
12x
(43219)




M6 Lock Washer
12x
(43273)



M6 Flat Washer
12x
(432731)




Tools




Phillips Screw Driver 1x

3



4



Hardware

M6x19mm Screw

8x
(43219)



M6 Lock Washer

8x
(43273)




M6 Flat Washer

8x
(432731)



Tools



Phillips Screw Driver 1x