TD5000 TD5001

3D Printer Cart



Assembly Guide TD5000_TD5001_2018_A

Check out our other products online at **www.copernicused.com**

For assistance, please contact us:


1-800-267-8494

Email info@copernicused.com

Have your packing slip ready for reference

WARNING

- · This product is meant to be assembled by an adult.
- In its unassembled state, small parts present a hazard.
- To be used under direct supervision of an adult.



TD5000

- 1 Tiny Tub
- **4 Open Tubs**
- 1 Really Big Tub



TD5001

- 1 Tiny Tub
- 2 Open Tubs
- 1 Tech Tub
- 1 Really Big Tub



TD5000 TD5001

3D Printer Cart



Assembly Guide TD5000_TD5001_2018_A

Check out our other products online at **www.copernicused.com**

For assistance, please contact us:

1-800-267-8494

Email info@copernicused.com

Have your packing slip ready for reference

Dear Educator,

Thank you for purchasing one of our products. I hope that your 3D Printer Cart is useful in your classroom.

If you have any questions, concerns, or ideas please contact us by telephone at 1-800-267-8494 or email at info@copernicused.com.

Enjoy using your new product and happy teaching.

Jim Phillips Chief Cook and Bottle Washer



of all true learning.

We do not inherit the earth from our ancestors, we borrow it from our children.

LEO BUSCAGLIA

Change is the end result

What you leave behind is not what is engraved in stone monuments, but what is woven into the lives of others.

Education is the most powerful weapon which you can use to change the world.

NELSON MANDELA

NORTH AMERICAN

PROVERB

PERICLES





Validate Your Warranty

To validate your warranty, submit the ON-LINE form at www.copernicused.com Enter a draw to win a Copernicus Product for your classroom at the same time!



Warning! Hazard Risks!

Please read the warnings below for important safety information regarding your product. Failure to read these warnings or to follow the instructions below could result in personal injury or damage to your product that could void your warranty.



Small Parts In its unassembled state, this product contains parts that can be hazardous to small children. This product should be assembled by an adult.



This product is to be used under the supervision of an adult.



This product is intended for indoor use only. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. The internal components are not sealed from the environment.



Power Strip
Specifications

Read your power strip electrical specifications. Only plug in devices that are approved for use with this power strip. Connect the supplied power strip directly to a wall outlet. **Do not connect to another power strip or use an extension cord.** Unplug when not in use. **Do not leave this product plugged in for more than 72 consecutive hours.** Turn off power strip before unplugging.



Read the electrical specifications of any electronic equipment you are using with your Copernicus products. Failure to read these specifications and follow their instructions could result in damage to your equipment or personal injury.



Hazard

Ensure that any cables extending across the floor to your product are properly bundled and marked to avoid tripping or falling which may lead to personal injury.




Do not install or use the electrical components of this unit during a lightning storm.



Do not climb on, hang from or suspend objects from any components of your product unless otherwise specified.

3D Printer Cart - Parts

Before beginning, you should have:



Tips for Assembly

Watch for These Helpful Symbols

- This symbol denotes a 2 Person Task. For safety, please ensure that there are the suggested number of people working on steps displaying this symbol.
- 2-Person Task
- Watch for this symbol throughout the Assembly Guide. Wherever you see it, pay close attention. The symbol denotes a step needing extra attention to ensure it is done correctly.



The star symbol highlights an advisory note.



Before You Begin

- Lay out and identify all of the included parts.
- The hardware has been packed according to **step**.
- Read the assembly guide over once to familiarize yourself with them.



Please note that in its unassembled state, this product contains parts that can be hazardous to small children. This product should be assembled by an adult.

Please note, star washers are critical components for electrical safety. Star washers must be included and fasteners fully tightened to prevent the risk of electric shock.



As You Assemble the Unit

- Follow the steps in sequence.
- Before beginning each step, find the part(s) that you need for that step.
- Pay attention to the labels on the parts; they are there to help direct you at certain stages.
- The title of each step states what you will be doing. Review the text and the pictures as you build the unit.

Customer Service - FAQ's



For missing parts and other issues regarding this product:

Please call Copernicus Customer Service, where we will be happy to help. 1-800-267-8494. Monday - Friday 8:30am - 4:30 pm EST.

OR

Email our Tech Support Service at info@copernicused.com

Check out some of our other great products!




www.copernicused.com


Need Tech Support? Have a Question?



Email our Tech Support Service





Attach Stretchers to Side Frame



Attach Middle Frame


Position main frame upside down to attach Middle Frame.






Install Casters

Lock Caster breaks before installation to make it easier to thread Casters into the cart legs





PLEASE KEEP WRENCH WITH UNIT.
Casters need to be tightened every
6 months for proper maintenance.



Install Really Big Tub Frame


Slide Really Big Tub frame into front of cart frame and install safety bolts







Attach Handle


Note orientation of handle in diagram.









Install Laptop Tray




Install Printer Table.







Install Spool Holder Arms.




Install Tiny Tub in holder.






Attach Power Strip

Attach Power Strip to the cart by using the supplied double sided tape. Install on the same side as the handle. Install on the stretcher shown below. Wrap cord around hooks on back of unit.





Install Tubs

